



1234 BELLEVUE STREET
GREEN BAY, WI 54302
Phone: 920-468-6828
info@biebelscatering.com
www.biebelscatering.com

COFFEEMAKER

GENERAL INFORMATION & INSTRUCTIONS

OPERATING INSTRUCTIONS:

1. Fill the coffee pot with COLD water to the desired amount.
2. Add coffee to the basket (see equivalents below).
3. Plug coffeemaker into a standard electrical outlet.
4. Turn on switch if there is one.
5. The red light will come on when the coffee is done brewing.
6. When coffee has finished brewing, remove the grounds basket. The pot will keep the coffee hot.

CLEANING:

Rinse out the inside of the coffee pot and basket. Never immerse the coffeemaker in water!

BREWING TIME:

Approximately ½ hour to brew coffee in 30-60 cup urns.

Approximately 1 hour to brew in 90 to 100 cup urns.

COFFEE EQUIVALENTS:

<u>Number of Cups</u>	<u>Coffee Measure</u>
55	3 1/3 cups
100	6 2/3 cups

1 lb. of coffee is equal to approximately 4 ¾ cups of ground coffee.

RETURNING:

Return the coffeemaker by 12:00pm the next business day unless other arrangements have been made. When returning equipment to Biebel's, please check in at the service counter.