



3' x 4' RED GAS TRAILER GRILL

GENERAL INFORMATION & INSTRUCTIONS

OPERATING INSTRUCTIONS FOR GRILLING:

1. Before lighting, make sure:
 - a. The three gas knobs are in the "off" position.
 - b. The three gas flow levers are in the "off" (horizontal) position.
 - c. The two burner control levers are in the "off" (horizontal) position.
2. Open the lid on the grill (and on the gas burners, if you are going to use them).
3. Turn on the propane tank wide open.
4. Lighting the three gas burners:
 - a. Open the three levers.
 - b. You can light the grill from the top or the side; lighting from the top is the best.
 - c. First remove the top grate. You will see three burners. The center one will be totally covered with the reflector. You may have to move it to get to the burner.
 - d. Light one burner at a time. Turn on one gas knob and light the burner.
 - e. Repeat the process on the remaining two burners.
 - f. Replace the reflector and the top grate.
5. On this particular grill, we usually run the back burner on about half, the middle burner on about two-thirds or full and the front burner on half. Adjust as needed.
6. This grill works best if the cover is closed most of the time.

SHUTTING OFF THE GRILL:

1. Turn off the burner knobs.
2. Turn off the gas flow levers.
3. Turn off the propane.
4. If you were using the two burners, turn these off also.

CLEANING:

1. You are responsible for cleaning the grill once done grilling. If it is not cleaned properly, you will not get your deposit returned.
2. While the grill is still on or warm, scrape the top grate with a wire brush.
3. If you used wood chips or sawdust to smoke, clean off the reflector pan and clean out the bottom of the grill.
4. Clean the outside of the grill with 409 or something similar.

RETURNING:

Return the grill by 12:00pm the next business day unless other arrangements have been made. When returning equipment to Biebel's, please check in at the service counter before bringing in the equipment. The staff person will tell you what door or area to return the items to.

After the grill has been checked in and noted if it was cleaned properly or not and the propane has been filled and recorded you will either be charged for the difference or given a refund. This usually does not happen the same day as the return.